



Bright, colorful and efficient: discover the future of QD-microLEDs with QustomDot





Introduction

QustomDot's focus

Technology progress

Advancements towards microLED-CC

Business model and collaboration

How QustomDot can be of service



Introduction

QustomDot's focus

Technology progress

Advancements towards microLED-CC

Business model and collaboration

How QustomDot can be of service



QustomDot

4

Location

Belgium-based technology start-up





QustomDot

5

Location

Belgium-based technology start-up

Spin off

Ghent University

Research group of Prof. Zeger Hens



Prof Dr. Ir. Zeger Hens



QustomDot

6

Location

Belgium-based technology start-up

Spin off

Ghent University

Research group of Prof. Zeger Hens

Financing

Venture backed

€3M venture capital seed round

Launch

Launched at the beginning of 2020



qbic fund



PMV
DOE- EN DURFBEDRIJF



VIGO
VENTURES



QustomDot

State-of-the-art lab facilities

7





QustomDot

A motivated and talented team

8






9

Colorful, functional and efficient: discover the possibilities of quantum dots (QD) with QustomDot.

We develop on-chip grade, RoHS compliant QD technology for future applications in color conversion.

Quantum dots (QDs) are semi-conductor nanocrystals that can absorb blue or UV light and emit a pure color. The emitted color depends on QD size.







11

QustomDot's focus


QustomDot focusses on MicroLEDs applications due to the enormous potential of the technology and its value:



Better
brightness,
lifetime and
Efficiency




Whole new
range
of applications




Integration of
other
functionalities in
the display





MicroLED challenges




Need for
wafer uniformity



Cost &
performance of
red μ LEDs



Complex driving
electronics




Mass transfer is
complex and
expensive



Inspection and
repair is
expensive



Overcome challenges with QDs



For mass transfer, all-in-one transfer, 3D structures, monolithic integration, ...




14

MicroLED industry challenge:
Find the **best** possible QD technology



Great
optical
properties



On-chip
grade



RoHS
compliant

A glass vial with a red cap and a blue glow in the background. The vial is on the left side of the image, and the blue glow is on the right side. The background is dark.

Introduction

QustomDot's focus

Technology progress

Advancements towards microLED-CC

Business model and collaboration

How QustomDot can be of service




The 5 QustomDot Pillars

16




QD Synthesis



QD Surface



QD Resin/ink



QD Patterning



QD Device




The 5 QustomDot Pillars

17



QD Synthesis




QD Surface



QD Resin/ink



QD Patterning



QD Device





18

Aminophosphine route for efficient InP QDs

Patented synthesis method using aminophosphine as phosphor source:

- Low-cost and safe to handle precursors
- Near unity chemical yield
- Size tuning through In-halide salts






19

Aminophosphine route for efficient InP QDs

Decent optical properties, but not excellent:

- PLQY: 50-60%, outliers >75%
- Linewidth: 45-50 nm
- Wavelength range in dispersion: 525-640 nm





20


Aminophosphine route for efficient InP QDs

Red QDs (~ 605 nm)

- PLQY >95% in well purified dispersions
- Linewidth 43-45 nm

Green QDs (~ 525 nm)

- PLQY >95%
- Linewidth 40-43 nm



Chem. Mater. 2019, 31, 9, 3476-3484




Aminophosphine route for efficient InP QDs

21

Shifting emission wavelength of green QDs towards cyan emission

- Required to reach green emission in highly concentrated films
- Tuning of aminophosphine synthesis parameters yields high quality cyan QDs
- Chemical yield >95% (similar to red QDs)
- First focus on wavelength, then on PLQY






Aminophosphine route for efficient InP QDs

22

Cyan QDs (~ 495 nm)

- Wavelength shift to 490-500 nm
- PLQY >90%
- Linewidth <44 nm




Chem. Mater. 2019, 31, 9, 3476-3484



QD synthesis – conclusions

23


- Cyan and red QDs synthesized at 95-100% chemical yield
- €/emitted photon favors amoniphosphine route
- Red, green and cyan QDs at near unity PLQY






The 5 QustomDot Pillars

24




QD Synthesis



QD Surface




QD Resin/ink



QD Patterning



QD Device



QD ligand exchange

25


The composition of the ligand shell influences:

- Optical properties
- Dispersibility in solvents and matrices
- Photoluminescent quantum yield
- Chemical stability
- Photostability
- ...


Many possibilities in the exchange methods and final ligand shell composition

Target: Establish ligand exchange procedure that preserves PLQY and yields resins with >10 V% QDs


The covalent bond classification




L-for-L exchange




X-for-X exchange



NC(Z) displacement



Nature Materials, **15**, pages 517–521 (2016)



QD ligand exchange – increasing solid loading

26

QDs in apolar medium




Ligand exchange



UV-curable, high solid loading resin



1-20 V% QDs





27

QD ligand exchange – preserving PLQY

Optimization of ligand exchange reactions

- Gradual improvement of results
- 90-100% of initial PLQY preserved, both for red and cyan QDs







QD ligand exchange – conclusions

28

- Ligand exchange methods developed for high solid loading resins (10-20 V%)
- 90-100% of initial PLQY retained after ligand exchange









Absorption in thin film

Absorption measurements

- Uniform test samples made with bar coater
- Substrate: 5x5 mm² pre-grooved borofloat glass
- Thickness range: 4-40 μm
- Absorption determined through integrating sphere measurements







Absorption in thin film

2021 progress

- 9-fold increase of absorption in 10 μm films
- $\sim 90\%$ of 450 nm light absorbed
- Both for red and cyan QDs
- Absorption/thickness range for microLED within reach






Absorption in thin film

31


- Further increase to 95-99% absorption planned for 2022
- Red and cyan InP-based QDs promising for microLED down-conversion






The 5 QustomDot Pillars

32



QD Synthesis



QD Surface



QD Resin/ink



QD Patterning




QD Device



Formulation of QD resins


33



QD surface expertise is a crucial part of a successful ink or photoresist formulation, but not the only part




QustomDot's approach makes a good link between the QD surface and the matrix – important for successful implementation






The 5 QustomDot Pillars

34




QD Synthesis



QD Surface




QD Resin/ink



QD Patterning



QD Device



Patterning of QD resins

35



Target: pattern $20 \times 20 \mu\text{m}^2$ features (short term)
move to $< 10 \times 10 \mu\text{m}^2$ in 2022-2023




QustomDot is actively looking for collaborations/partnerships to make demonstrators




The 5 QustomDot Pillars

36



QD Synthesis




QD Surface




QD Resin/ink



QD Patterning



QD Device



Photostability – thick QD films





300-500 μm




1 W/cm^2



1-2 V%





Photostability – thick QD films





300-500 μm




1 W/cm^2



1-2 V%





Photostability – towards thinner films




100-150 μm




0.1 W/cm^2



1-2 V%





Photostability – towards **microLED**





15-20 μm




0.1 W/cm^2



~10 V%





Photostability – towards **microLED**




15-20 μm



0.1 W/cm^2



~10 V%



250h of
stability



Intensity
 W/cm^2

1

0.1

0.1




The 5 QustomDot Pillars

42




QD Synthesis



QD Surface



QD Resin/ink



QD Patterning



QD Device

A glass vial with a red cap and a blue glow. The vial is on the left side of the image, and a blue glow is visible on the right side. The background is black.

Introduction

QustomDot's focus

Technology progress

Advancements towards microLED-CC

Business model and collaboration

How QustomDot can be of service




The market potential is huge

44 There are various applications where on-chip grade QDs could make the difference.



Automotive
head-up displays

\$80B




MicroLED
TVs & laptops

\$45B & \$11B




AR/VR
goggles

\$6B



Smartphones

\$51B



Smart
watches

\$2B



Our business model

45

QustomDot develops on-chip grade QD technology for MicroLED manufacturers.

We produce an QD ink/photoresist through an industrialization partner (to be determined).





The 5 QustomDot Pillars

46



Own expertise



The 5 QustomDot Pillars

47




QD Synthesis



QD Surface



QD Resin/ink



QD Patterning



QD Device

Partnerships



Thank you for your attention

48



Dr. Willem Walravens
founder, CTO
willem@qustomdot.com



Dr. Kim De Nolf
founder, CEO
kim@qustomdot.com



Dr. Igor Nakonechnyi
founder, CPO
igor@qustomdot.com

